

# PRE-FILTER BASKET™

## Installation Instructions

---



Place Pre-Filter basket against wall around Petro-Pipe. Put the 'Z' brackets against the Pre-Filter flange and drill holes.

Attach the 'Z' brackets with concrete anchors. The Pre-Filter basket can now be removed by sliding up.

---

Lift the lid and fill the cage with the 2" floss batting. Push it down below the top so that the lid can close.



The Petro-Pipe is now protected from dirt and debris. To keep optimum water flow inspect and clean or replace floss batting as needed.

The pre-filter basket will have to be removed in order to replace the Petro-Pipe.

---